

Airvac Solar Light Monitor

Easily identify the affected valve pit if an issue should occur.



Solar Light Benefits

- Activates if high sewage sump levels occur.
- Flashes if the valve remains open longer than 15 seconds.
- Allows operators to easily identify which valve pit is affected.
- Is easily visible from a long distance.

Installation

A solar light monitor is mounted on the air terminal and connects to the sump breather and the vacuum valve. The solar light monitor can signal a high sewage sump level via the breather or a valve failure via the vacuum valve. The light is easily visible from a long distance, avoiding the need for operators to physically check every vacuum valve in the system.



The solar light monitor is easily visible from a long distance, avoiding the need for operators to physically check every vacuum valve in the system.



Airvac

A brand of Aqseptence Group 4217 N Old US Highway 31 Rochester, IN 46975 Phone +1 574 223 3980 info.airvac@aqseptence.com